



C3414 CPU Manual

C3414-AAA-00001 V1.2

Schneider Electric North America Headquarters
1415 South Roselle Road
Palatine, IL 60067

Phone: 1-847-397-2600
Fax: 1-847-925-7500

Schneider Electric
14400 Hollister St., Suite #400
Houston, TX 77066-5706

Phone: 1-713-920-6800
Fax: 1-713-920-6909
E-mail: sagesupport@schneider-electric.com

C3414 CPU Manual

For Reference Only

© Copyright 2014 by Schneider Electric

The information contained in this document is confidential and proprietary to Schneider Electric. It is not to be copied or disclosed for any purpose except as specifically authorized in writing by Schneider Electric. Although the information contained herein was correct and verified at the time of publication, it is subject to change without notice.

Manual No. **C3414-AAA-00001**

Document Approval

Rev	Date	Description	ECO #	Technical Review	Admin. Approval
0.0	04-27-10	Initial Release	N/A		
1.0	10-23-12	Update	N/A		
1.1	12-10-2013	Updates for Schneider	N/A		
1.2	12-08-2014	Minor Updates for Drawings			
				Garry Macejewski, Manager, RTU Engineering	Dan Stark, Manager, RTU S/W Engineering

1 Introduction


1.1 CPU/Memory

BOARD SIZE	4.250" x 3.775"
DRAM	256 MB
OPERATING TEMPERATURE	-40° C to 85° C
SYSTEM RESET	Voltage sensing, resets when the 3.3V power rail varies by more than +/- 10% of its optimal value. Watchdog timeout
ETHERNET INTERFACE	Two Intel 82551ER based Fast Ethernet 10/100 Controllers and half/full duplex autonegotiated
COM1-2 INTERFACE	RS-232, 16C550 compatible, 115k baud max
BIOS	General Software Embedded BIOS with OEM enhancements. Field upgradable with Flash BIOS Upgrade Utility
BUS SPEED	CPU Bus: 800 MHz (Celeron equiv), 500 MHz actual.
COMPATIBILITY	PC/104 – full compliance
WEIGHT	0.102 kg (3.616 oz)
GENERATED FREQUENCIES	32 KHz, 8.25MHz, 14.318MHz, 33MHz, 48MHz, 66MHz, 166.5MHz

1.2 Visual Indicators

PC/104 CPU LEDs	D1 - Green Secondary Ethernet Link/Activity (ON=Active Link, BLINK=RX/TX data activity) Yellow Secondary Ethernet 1 Link Speed (ON=100baseT, OFF=10baseT) D2 Green Primary Ethernet 0 Link/Activity (ON=Active Link, BLINK=RX/TX data activity) Yellow Primary Ethernet 0 Link Speed (ON=100baseT, OFF=10baseT)
-----------------	--





Only connectors J2, J3, J5, J7 and J9 are used in RTU application.

2 Processor Overview

2.1 PC/104 Architecture

The open architecture of the PC/104 bus interface provides for expanded functions. You may add a PC/104-based C3461GPS receiver, C3437/C3438 Communication cards that allow up to eight additional Comm ports, a C3830 analog to digital card or a C3831 IRIG B interface card.

The PC/104 architecture is a compact version of the IEEE P996 (PC and PC/AT) bus, optimized for the unique requirements of embedded systems applications. The PC/104 bus derives its name from the 104 signal contacts on the two bus connectors (64 pins on P1, plus 40 pins on P2). The main differences from the IEEE P996 are:

1. Reduced form-factor (4.250 x 3.775 inches)
2. Self-stacking, eliminating need for backplanes or card cages
3. Minimized component count and power consumption (typically 1-2 watts per module) and reduced bus drive requirement (typically 4 mA)

2.2 SAGE RTU Microprocessor Overview

The RTU uses a PC/104-based CPU card as the engine for the system. The LX 800 microcontroller has a 32-bit, low-voltage AMD x86 CPU microprocessor at its core. It provides the RTU with the benefits of high performance, low cost, and low power consumption, while maintaining compatibility with the large base of industry-standard 32-bit software. The high performance of the processor is because of its 500 MHz operating clock frequency and architectural features which include pipelining, reduced clock cycle instruction fetches, reduced instruction set, and an integrated memory management unit.

2.3 Hardware Design

2.3.1 VersaLogic Model EPM-14 CPU Card

The EPM-14 (Cougar) is an AMD LX 800 based processor board in a compact PC/104-Plus format. It is specifically designed for OEM control projects requiring compact size, high reliability, and long product lifespan / availability.

Further documentation for this board may be obtained from the vendor.

VersaLogic Corporation
www.versalogic.com
3888 Stewart Road
Eugene, OR 97402
(541) 485-8575
Fax (541) 485-5712

2.3.1.1 Geode LX 800 CPU

The Geode LX 800 microcontroller combines a 32-bit, low-voltage AMD x86 CPU with a complete set of integrated peripherals suitable for both real-time and PC/AT-compatible embedded applications. The device also features a 32-bit PCI bus, a high-performance, 32-bit SDRAM interface and a full-featured, high-performance in-circuit emulation capability, known as the AMDebug™ technology.

You may learn more about the microprocessor directly from the OEM:

2.3.1.1.1 Technical Support

Answers to technical questions are available online, through e-mail, and by telephone.

Go to AMD's home page at www.amd.com and follow the Support link for the latest AMD technical support phone numbers, software, and Frequently Asked Questions.

For technical support questions on all E86 products, send e-mail to epd.support@amd.com (in the US and Canada) or euro.tech@amd.com (in Europe and the UK).

You can also call the AMD Corporate Applications Hotline at:

(800) 222-9323 Toll-free for U.S. and Canada

44-(0) 1276-803-299 U.K. and Europe hotline

2.3.1.1.2 WWW Support

For specific information on E86 products, access the AMD home page at www.amd.com and follow the Embedded Processors link. These pages provide information on upcoming product releases, overviews of existing products, information on product support and tools, and a list of technical documentation. Support tools include online benchmarking tools and CodeKit software—tested source code example applications. Many of the technical documents are available online in PDF form.

Questions, requests, and input concerning AMD's WWW pages can be sent via e-mail to webfeedback@amd.com.

2.3.1.2 Socketed Battery

The battery on the EPM-14 PC/104 CPU card is a rechargeable 3.5V Lithium cell.

2.3.1.3 LEDs

LEDs D1 and D2 are dual LEDs, one segment yellow and the other green. LED D1 is used to indicate activity on Ethernet 1 (Secondary) while LED D2 is used to indicate activity on Ethernet 0 (Primary).

2.3.1.3.1 Link/Activity LED (GREEN)

ON Active Ethernet cable plugged into connector. No Tx/Rx data activity.

OFF Cable not plugged into connector. Cable not plugged into active hub.

BLINKING Active Ethernet cable plugged into connector. Tx or Rx data activity detected on the cable.

2.3.1.3.2 Speed LED (YELLOW)

ON 100Base-T (Fast) detected on Ethernet cable.

OFF 10Base-T (Slow) detected on Ethernet cable.

2.3.1.4 PC/104 Bus Interface/Connector


The bus interface connector is compatible with the PC/104 Consortium specification.

Contact the Consortium at:

PC/104 Consortium
849 Independence Ave., Suite B
Mountain View, CA 94043
Phone: 650.903.8304
Fax: 650.967.0995
Email: info@pc104.org

The PC/104 standard is available on the web in downloadable PDF format at:

URL: <http://www.pc104.org>



3 RTU Upgrades

3.1 CPU Upgrade Kit (C3414-KIT-800UG)

The upgrade to the C3414 CPU card may be delivered through Schneider-Electric Houston Customer Service. The kit consists of the C3414 CPU card with a Compact Flash memory loaded with Schneider-Electric firmware, a ribbon cable that connects to the baseboard, an Ethernet cable, and 4 sets of mounting screws/washers.

This kit comes installed as part of any SAGE RTU that is ordered with this CPU.

Important Note: If you are upgrading or replacing the CPU, download and store in a safe place your configuration file from the old card in order to have it available for configuration conversion.

The parts list for the kit is shown below.

=====									
PRODUCT: C3414-KIT-800UG						PRINTED ON:		SALES	
ORDERS									
DESC: UPGRADE KIT 3/4/586 TO 800-CPU						SHIPPING			
DOCUMENTS									
UM: EA						PACKING			
LISTS									
INVOICE/CREDIT									
MEMOS									
=====									
						QUANTITY			
MANUFACTURING						PER			
PART NUMBER		DESCRIPTION				PRODUCT		SERIAL	
NUMBER									
-----		-----				-----		-----	
B0000-079-11500		CBL	ETHERNET	10B-T	CO	15FT	0	1.000	
UNRESTRICTED									
C3413-CB1-00007		CBL	ASSY	FLAT	FF	50/10	00F0	1.000	
UNRESTRICTED									
C3414-000-00001		PCA	CPU	LX800	W/CF/IMG/LIC		1	1.000	
UNRESTRICTED									
J0203-185-00000		WASHER	LOCK	INT	NO	3	SS	4.000	
UNRESTRICTED									
J4001-242-00000		SCREW-MACH			4-40	BH	SS	03	4.000
UNRESTRICTED									

SAGE 1110, 1210, 1310 may be upgraded to a SAGE 1410.

Important Note: SAGE 1110, 1210, 1310 must be returned to Schneider-Electric for upgrade if the User Interface DB3 is not a right angle connector.


SAGE 1130, 1230, 1330 may be upgraded to a SAGE 1430.

SAGE 1150, 1250, 1350 may be upgraded to a SAGE 1450.

SAGE 2100, 2200, 2300 may be upgraded to a SAGE 2400.


SAGE 3030 may be upgraded to a SAGE 3030M; the unit must be returned to Schneider-Electric in order to upgrade it.

The C3414 card with the ribbon cable is shown below. Note how the ribbon cable must go beneath the CPU card. This does not apply to the SAGE 3030. The SAGE 3030 ribbon cable is different from the one pictured.



The ribbon cable itself is depicted below. Note that the small connectors are keyed to plug into J1 on the baseboard. They are also labeled CONSOLE and PPP PORT. Whichever connector is not being used may float free (unconnected).

Important Note Do not remove the ribbon cable once it is connected.



3.2 Configuration Update

If the CPU card you are replacing meets the following requirements, it may be updated with your previous CPU configuration by following directions on the Configuration Update document on the Customer website.

You should download and store in a safe place your configuration from the old card in order to have it available for configuration conversion.

Hint: You should also run the Configuration Conversion program on your existing configuration to make sure that it converts properly with no errors before installing the C3414 CPU.

Firmware configurations from the SAGE 1210 and SAGE 1310 may be converted and used in the SAGE 1410.

Firmware configurations from the SAGE 1230 and SAGE 1330 may be converted and used in the SAGE 1430.

Firmware configurations from the SAGE 1250 and SAGE 1350 may be converted and used in the SAGE 1450.

Firmware configurations from the SAGE 2200 and SAGE 2300 may be converted and used in the SAGE 2400.


Firmware configurations from the SAGE 3030 may be converted and used in the SAGE 3030M.

3.3 CPU Card Connections

3.3.1 Console

For normal operation (non-PPP), place the ribbon cable that does NOT have the red stripe into J1 on the baseboard as shown below. This is console position.


Figure 3-1 Console Operation



3.3.2 Point-to-Point Protocol (PPP)

For PPP operation, place the ribbon cable that has the red stripe into J1 as shown below.

Figure 3-2 PPP Operation



3.3.3 Ethernet


Ethernet 0 is the primary Ethernet connector and is active when the RTU is powered.

Ethernet 1 is the secondary Ethernet connector and is active only after it has been configured via the GUI and Application firmware.

3.4 PC/104 Card Stacking

The PC/104 cards should be stacked with the CPU card on top, as shown in Figure 3-3, except in the case of the installation of the C3463 Ethernet Switching Hub, which, because of clearance restrictions, must be installed on top.

Figure 3-3 PC/104 Card Stacking




3.5 PC/104 Card Jumpers

3.5.1 GPS Card C3461

The GPS card jumpers should be verified to be as shown in Figure 3-4.

Figure 3-4 GPS Card C3461 Jumpers for a C3414 CPU



3.5.2 Communications Expansion Card C3437

The jumpers for the Communications Card(s) should be placed as shown in Figure 3-5 and Figure 3-6.

Figure 3-5 Communication Expansion Card C3437 – Board #1






Figure 3-6 Communication Expansion Card C3437 – Board #2



4 Console Commands

4.1 Logging In/Out

With the introduction of the Secure firmware, the user must Login to use Console. When finished using Console the user must exit by typing Ctrl D. See below.



4.2 List of Console Commands

The console now has two command modes, “C” and “cmd”.

Typing “cmd” at the console will bring you to the [VxWorks]# command prompt:

```
-> cmd
```

```
[vxWorks]#
```

```
[vxWorks]# help
```

At [VxWorks Boot] prompt, type help to get list of options

List of the registered topics:

VM	List of the shell commands related to virtual memory.
basic	List of basic shell commands.
breakpoint	List of the shell commands related to breakpoints.
filesystem	List of the shell commands related to file system.
history	List of commands relative to history management.
interpreter	Interpreter shell commands.
memory	List of the shell commands related to memory.
modules	List of the shell commands related to kernel modules.
network	Network commands
object	List of the shell commands related to objects.
symbols	List of the shell commands related to symbols.
tasks	List of the shell commands related to tasks.
vxmux	VXMUX routines

List of the registered commands:

C	Switch to C interpreter
aes_ccm_test	aes_ccm_test
aesgcmtest	aesgcmtest
aeskeywraptest	AES-Keywrap test utility.

alias	Add an alias or display alias
arp	IPNET arp control
asn1parse	Parse an ASN.1 sequence
bftest	bftest test utility.
bntest	Big number test utility.
bp	Display, set or unset a breakpoint
ca	Certificate Authority (CA) Management
casttest	casttest test utility.
cd	Change current directory.
ciphers	SSL Cipher Suites
cmactest	AES-CMAC test utility.
cmp	cmp
cpu	Set/Get CPU affinity
crl	Certificate Revocation List (CRL) Management
date	Show/Set current date
demangle	Display demangled string
destest	destest test utility.
dgst	Message Digest Calculation
dh	Diffie-Hellman Parameter Management. Obsoleted by
dhparam	
dhparam	Generation and Management of Diffie-Hellman Parameters
dhtest	dhtest test utility.
dprintf	Insert a dynamic printf eventpoint
dsa	DSA key processing
dsaparam	DSA parameter manipulation and generation
dsatest	dsatest test utility.
echo	Display a line of text
echoclient	TCP/UDP echo client
echoserver	TCP/UDP echo server
enc	Encoding with Ciphers
engine	Hardware Crypto Support
enginetest	engine test utility.
evp_test	evp_test test utility.
exit	Exit the shell session.
expr	Evaluate expressions
exptest	Big number test utility.
file ...	
func ...	
gendh	Generation of Diffie-Hellman Parameters. Obsoleted by
	dhparam
gensdsa	Generation of DSA Parameters
genrsa	Generation of RSA keys
getenv	Get an environment variable
help	Display the list of the shell commands
history ...	
hmactest	hmactest test utility.
ifconfig	IPNET interface configuration
ipcrypto_ver	Show IPCRYPTO version
ipd	ipd - Interpeak daemon control
ipf	Firewall
ipsecctrl	config ipsec
ipssh_list	List connected ssh clients
ipssh_stop	Stop SSH spawns
ipversion	Show interpeak product versions

keyadm	admin IPsec keys
keydb	Key DB admin command
keyfp	Generate key finger print
logout	Logout the shell session.
lookup	Lookup a symbol
macsec	MACsec commands
md2test	md2test test utility.
md4test	md4test test utility.
md5test	md5test test utility.
mem ...	
module ...	
more	Browse and page through a text file.
netstat	IPNET socket and route stats
nseq	Create or examine a netscape certificate sequence
nslookup	Query Internet name servers interactively
object ...	
ocsp	ocsp - Online Certificate Status Protocol utility
passwd	Generation of hashed passwords
pcap	Packet capture utility
ping	IPNET ping utility
pkcs7	PKCS#7 Data Management
pkcs8	PKCS#8 format private key conversion tool
print ...	
printf	Write formatted output
pwd	Display current working directory.
qc	IPNET output queue configuration
qos	IPNET Quality of Service configuration
radiusc	Radius client
rand	Generate pseudo-random bytes
randtest	randtest test utility.
rc2test	RC2 test utility.
rc4test	RC4 test utility.
reboot	Reboot the system
repeat	Repeat a command
req	X.509 Certificate Signing Request (CSR) Management
rmctest	rmctest test utility.
route	IPNET route table control
rsa	RSA Data Management
rsa_test	rsa_test test utility.
rsautl	RSA utility for signing, verification, encryption, and decryption
s_client	SSL client
s_server	SSL server
s_time	Time SSL connection
set ...	
setenv	Set an environment variable
sftp	sftp file transfer
shaltest	shaltest test utility.
sha512test	sha512 test utility.
shatest	shatest test utility.
show ...	
slab	Print slab cache information
sleep	Suspend execution for an interval.
smime	S/MIME mail processing

speed	Test encryption performance
spkac	SPKAC printing and generating utility
spy ...	
ssl_clt	SSL client for performance measurements
ssl_srv	SSL server for performance measurements
sslmem	sslmem
ssltest	ssltest
string ...	
sysctl	IPNET sysctl configuration
syslog	syslog
sysvar	System variable tool
tabtest	X509 test utility.
task ...	
time	Show/Set current time
tip	Connect to one or several remote systems over serial
lines.	
traceroute	Trace route command for IPv4
ttcp	ttcp - standard performance test
ttcp1	ttcp - min priority
ttcp7	ttcp - max priority
unalias	Remove an alias
unset ...	
user	User admin command
verify	X.509 Certificate Verification
version	Display VxWorks version information.
vm ...	
vxslab	Print VXMUX slab cache information
x509	Certificate display and signing utility

Typing “C” (uppercase only) at the will switch back to the C interpreter:

```
[vxWorks]# C
->
->
->
-> help
help          Print this list
dbgHelp       Print debugger help info
edrHelp       Print ED&R help info
ioHelp        Print I/O utilities help info
nfsHelp       Print nfs help info
netHelp       Print network help info
rtpHelp       Print process help info
spyHelp       Print task histogrammer help info
timexHelp     Print execution timer help info
h             [n]          Print (or set) shell history
i             [task]       Summary of tasks' TCBs
ti            task        Complete info on TCB for task
sp            adr,args...  Spawn a task, pri=100, opt=0x19, stk=20000
taskSpawn    name,pri,opt,stk,adr,args... Spawn a task
tip          "dev=device1#tag=tagStr1", "dev=device2#tag=tagStr2", ...
                                     Connect to one or multiple serial lines
td            task        Delete a task
ts            task        Suspend a task
tr            task        Resume a task
```


Type <CR> to continue, Q<CR> or q<CR> to stop:

tw	task	Print pending task detailed info
w	[task]	Print pending task info
d	[adr[,nunits[,width]]]	Display memory
m	adr[,width]	Modify memory
mRegs	[reg[,task]]	Modify a task's registers interactively
pc	[task]	Return task's program counter
iam	"user"[,"passwd"]	Set user name and passwd
whoami		Print user name
devs		List devices
ld	[syms[,noAbort][,"name"]]	Load stdin, or file, into memory (syms = add symbols to table: -1 = none, 0 = globals, 1 = all)
lkup	["substr"]	List symbols in system symbol table
lkAddr	address	List symbol table entries near address
checkStack	[task]	List task stack sizes and usage
printErrno	value	Print the name of a status value
period	secs,adr,args...	Spawn task to call function periodically
repeat	n,adr,args...	Spawn task to call function n times (0=forever)
version		Print VxWorks version info, and boot line
shConfig	["config"]	Display or set shell configuration variables

Type <CR> to continue, Q<CR> or q<CR> to stop:

strFree [address] Free strings allocated within the shell (-1=all)

NOTE: Arguments specifying 'task' can be either task ID or name.

value = 1 = 0x1
->

Some of the more common “C” commands not listed in help:

setip	Set the IP address of the RTU
whoru	Get the RTU IP address

Commonly used “cmd” command not listed in help

reboot Reboot the RTU

4.3 Recovering From a Corrupt IP Address

If an illegal character has been entered as an IP address, the bootup process will stop at the [VxWorks Boot] prompt. The condition can be corrected by following the example below.

```
-> setip "172.18.1%0.51:ffff800"
OK.
value = 4 = 0x4
-> reboot 2
```

Accidentally entered IP address with an illegal character. Once you hit Enter, you are stuck. Go ahead and reboot, as shown.

(With a “bad” IP address, the RTU continuously reboots. Carefully watch the display until the following message appears:

Press any key to stop auto-boot...

1

[VxWorks Boot]: ?

At [VxWorks Boot] prompt, type ? to get list of options

Commands:

?	- print this list
@	- boot (load and go)
p	- print boot params
c	- change boot params
l	- load boot file
g adrs	- go to adrs
e	- print fatal exception
v	- print boot logo with version
d adrs[,n]	- display memory
m adrs	- modify memory
f adrs, nbytes, value	- fill memory
t adrs, adrs, nbytes	- copy memory
devs	- print system devices

Bootline Format:

```
$dev(0,procnum)host:/file h=# e=# b=# g=# u=usr [pw=passwd] f=#
tn=targetname s=script o=other
```

File System Boot Device Formats:

```
boot device: fs
file name: /FileSystemDeviceName/vxWorks
other: network device name
```

```
boot device: ata[=ctrl,drive]          file name: /ata0a/vxWorks
```

Boot Flags:

```
0x0002 - load local system symbols
0x0004 - don't autoboot
0x0008 - quick autoboot (no countdown)
0x0080 - use tftp to get boot image
```

Available Boot Devices:

```
Filesystem Devices: /ata0a /ata00:2
Enhanced Network Devices: fei0 fei1
```

[VxWorks Boot]: p

Type “p” to verify the incorrect IP address

```

boot device      : ata=0,0
unit number     : 0
processor number : 0
host name       : host
file name       : /ata0a/vxworks
inet on ethernet (e) : 172.18.1%0.51:ffff0000
host inet (h)    : 172.18.150.49
gateway inet (g) : 172.18.1.1
user (u)        : target
ftp password (pw) : password
flags (f)       : 0x8
target name (tn) : Telvent
other (o)       : fei

```

The Problem

Change boot parameters one step at a time by entering lowercase "c"

[VxWorks Boot]: c

'.' = clear field; '-' = go to previous field; ^D = quit

```

boot device      : ata=0,00
processor number  : 0
host name       : host
file name       : /ata0a/vxworks
inet on ethernet (e) : 172.18.1%0.1:ffff0000 172.18.150.1:ffff0000
inet on backplane (b):
host inet (h)    : 172.18.150.49
gateway inet (g) : 172.18.1.1
user (u)        : target
ftp password (pw) (blank = use rsh): password
flags (f)       : 0x8
target name (tn) : Telvent
startup script (s) :
other (o)       : fei

```

When the offending IP address comes up

Type in correct IP address & mask here. Continue to hit Enter until [VxWorks Boot] prompt appears

NOTE: Bootline not saved to NVRAM

[VxWorks Boot]: p

Print boot parameters to verify correct IP

```

boot device      : ata=0,0
unit number     : 0
processor number : 0
host name       : host
file name       : /ata0a/vxworks
inet on ethernet (e) : 172.18.150.1:ffff0000
host inet (h)    : 172.18.150.49
gateway inet (g) : 172.18.1.1
user (u)        : target
ftp password (pw) : password
flags (f)       : 0x8

```

```
target name (tn)      : Telvent
other (o)             : fei
```

One-time boot with this set of parameters

```
[VxWorks Boot]: @
```

```
-> setip "172.18.150.51:ffffff800"
OK.
value = 4 = 0x4
-> reboot 2
```

After normal bootup, you must now do setip again using the correct IP, then reboot again

After bootup, whoru to verify correct IP address.

```
-> whoru
IP Address = 172.18.150.51
Subnet Mask = 255.255.248.0
value = 28 = 0x1c
->
```


4.4 Booting the RTU in Safe Mode

To bootup in Safe Mode from the console, you must first reboot in console by logging in (if not already logged in), then type reboot 2 as shown below, and hit return.



Press any key repeatedly as login begins. The login will stop at [VxWorks Boot]: as shown below.

Enter a lower case c as shown below, and hit return.



```
COM8 - PuTTY

VxWorks System Boot


Copyright 1984-2008 Wind River Systems, Inc.

CPU: PC PENTIUM2
Version: VxWorks 6.8
BSP version: 2.0/13
Creation date: Jan 21 2011, 15:48:48

Press any key to stop auto-boot...
,1

[VxWorks Boot]: c
```

Keep hitting return to advance the cursor to flags (f) as shown below. Whatever number is displayed after the colon (in this case 0x28), add 1 to that number and enter the new number. The entered number entered must be odd.



```
COM8 - PuTTY


[VxWorks Boot]: c

'.' = clear field; '-' = go to previous field; ^D = quit

boot device      : ata=0,00
processor number  : 0
host name        : host
file name        : /ata0a/vxworks
inet on ethernet (e) : 172.18.150.171:ffff800
inet on backplane (b):
host inet (h)    : 192.168.1.50
gateway inet (g) :
user (u)         :
ftp password (pw) (blank = use rsh):
flags (f)        : 0x28 0x29
```

Enter the first number + 1.

Hit return until the cursor returns to [VxWorks Boot]: as shown below. Enter an "at" symbol, that is @ as shown, then hit return to continue bootup.



```
COM8 - PuTTY

Press any key to stop auto-boot...
n1


[VxWorks Boot]: c

'.' = clear field; '-' = go to previous field; ^D = quit

boot device      : ata=0,00
processor number  : 0
host name        : host
file name        : /ata0a/vxworks
inet on ethernet (e) : 172.18.150.171:ffff800
inet on backplane (b):
host inet (h)     : 192.168.1.50
gateway inet (g)  :
user (u)          :
ftp password (pw) (blank = use rsh):
flags (f)         : 0x28 0x29
target name (tn)  : Telvent
startup script (s) :
other (o)         : fei

NOTE: Bootline not saved to NVRAM
[VxWorks Boot]: @
```

The RTU will bootup in Safe Mode as shown below.



```
COM8 - PuTTY

Error: unable to open startup script '/ata0a/scripts/startup.scp'.
Rtu Application "/ata0a/c3414-500-s02h0.out" found!!!

VxWorks login: 0xc00bb8 (startup): startup: Http Server spawned successfully...
/ramDrv/ - Volume is OK


Web Server Version C3414-500-995H0
Oxc00bb8 (startup): startup: User Log spawned successfully...
Oxc00bb8 (startup): startup: RTU App starting at: 06/06/2012 14:55:50
Oxc00bb8 (startup): <<*****
>>
Oxc00bb8 (startup): << User has halted startup!!! Only HTTP Server Task started
>>
Oxc00bb8 (startup): <<*****
>>
```

4.5 Checking Task Status

Typing the lowercase **i** into the console prompt shows the status of all tasks running. The critical clue to watch for, if you suspect a problem, is the STATUS of each task. PEND, READY, and DELAY are okay, but a SUSP means trouble. See below.

For instance, the tHTTPd task serves up web pages to Internet Explorer. If this task is SUSP, then there will be no response in I.E. from the RTU.

Figure 4-1 Checking Task Status




NAME	ENTRY	TID	PRI	STATUS	PC	SP	ERRNO	DELAY
tIsr0	43eb60	166a7ec	0	PEND	63d1b0	16d5f80	0	0
tJobTask	5c96f0	166e250	0	PEND	63d1b0	16dbf30	0	0
tExcTask	5c8a70	7c1d20	0	PEND	63d1b0	7bf220	0	0
tLogTask	logTask	16d8978	0	PEND	63b06a	16e1ed0	0	0
tNbicLog	5ca6b0	166e6c0	0	PEND	63d1b0	16e8ef0	0	0
tShell10	shellTask	18839bc	1	READY	6452e0	18c8120	0	0
tWdbTask	wdbTask	1891010	3	PEND	63d1b0	18b6f00	0	0
tErftask	4460e0	16e5cf4	10	PEND	63d610	16edf20	0	0
ipcom_tick>	656080	187e348	20	DELAY	64320a	188af80	0	4
tAtaSvc0	432718	16de790	50	PEND	63d610	16c8f30	0	0
tNet0	ipcomNetTask	167cb10	50	PEND	63d1b0	170df20	6	0
ipcom_sys1>	462800	1841278	50	PEND	63d610	184ae50	0	0
ipcom_telnet>	ipcom_telnet	166c1e4	50	PEND	63d1b0	1881e00	0	0
ipppp_work	40c16d	168c100	50	PEND	63d610	188ff30	0	0
ipftps	ipftps_main	185a828	50	PEND	63d1b0	189ee10	0	0
ipiked	ipike_proc	1896b38	50	PEND+T	63d1b0	18b09b0	3d0004	3
tXbdService>	5c2650	18b86e4	50	PEND+T	63d610	18cdf40	3d0004	58
t5Msec	clk_task_5ms	ef26d4c	98	PEND	63d1b0	1b0df00	0	0
t50Msec	clk_task_50m	1b0a530	99	PEND	63d1b0	1b13f30	0	0
dcmgMain	dcmgMain	1c62e00	100	DELAY	64320a	1c69f80	1f5003d	22
ETCP	etcpMain	18849b0	100	DELAY	64320a	1c74f20	1f5003d	2
IsaIXD	dixdMain	1c7f6e8	100	DELAY	64320a	1c85f60	1f5003d	3
dnTcpSrv17	dnpTcpServ	1be2558	203	PEND	63d1b0	1c54c90	0	0
dnTcpWrk17	tcpProcess	1842000	203	PEND	63b06a	1c59eb0	0	0
dnUdpSrv17	dnpUdp	1843290	203	PEND	63d1b0	1c5ecf0	0	0
DBC	m1_dbc	1b8ab50	204	PEND+T	63d1b0	1b92f10	3d0004	122
SCHED	1a5d340	1b85eb0	205	PEND	63b06a	1b8ceb0	0	0
COS	m1_cos	1b90970	205	PEND+T	63b06a	1b98e70	3d0004	172
CTLR	m1_ctlr	1b90c60	205	PEND+T	63b06a	1b9fe00	3d0004	30
ANA	m1_ana	1b9d980	205	PEND	63d1b0	1ba6f10	0	0
DAC	m1_dac	1b9dd50	205	PEND+T	63b06a	1baddd0	3d0004	105
ISaGRAF_IF	1931950	1babc70	205	PEND	63d1b0	1bc49a0	30065	0
DNPMCOM 1	dnp_dl_task	1bc1c70	205	PEND+T	63d1b0	1be9ea0	3d0004	17
DNP COM 17	dnp_dl_task	1bd0c00	205	PEND+T	63d1b0	1c01ea0	3d0004	15
USERLOG	usrlog_task	ef279b0	206	PEND	63b06a	1af2e70	3d0002	0
MEM COM 2	mbm_task	1bd0980	206	DELAY	64320a	1bf9e20	3d0004	46
DNP_APPR17	dnp_appr_tas	1bd7980	206	PEND+T	63d1b0	1c09ea0	0	171
DNP_APPM1	dnp_appm_tas	1bc99f0	207	PEND+T	63d1b0	1bf1e50	3d0004	2
SOELOG	soelog_task	1bb2980	208	PEND+T	63d1b0	1bcbed0	3d0004	130
ALARMS	alarms_task	1bb2d68	208	PEND	63b06a	1bd2e90	0	0
SELF	m1_self	1ba4ad0	215	DELAY	64320a	1bb5a20	3d0001	57
GPST	gpst_task	1bab980	215	PEND+T	63d1b0	1bbcf30	3d0004	147

4.6 Pinging From The RTU

It has always been possible to ping the RTU from a device if you know the RTUs I.P. address. The RTU itself is now capable of sending a ping over TCP/IP with a console command. This function is useful if you want to check TCP/IP communication integrity directly from the RTU to any TCP/IP address compatible with the IP address range. See the syntax rules below.

Figure 4-2 Ping Syntax Rules



The following figure shows the result of a ping

Figure 4-3 Pinging From Within The RTU

```
COM1 - PuTTY
->
-> whoru
IP Address = 172.18.150.51
Subnet Mask = 255.255.248.0
value = -2048 = 0xffff800
-> ping "172.18.150.54",3,0
value = 0 = 0x0
->
Pinging 172.18.150.54 (172.18.150.54) with 64 bytes of data:
Reply from 172.18.150.54 bytes=64 ttl=64 seq=0 time=0ms
Reply from 172.18.150.54 bytes=64 ttl=64 seq=1 time=16ms
Reply from 172.18.150.54 bytes=64 ttl=64 seq=2 time=33ms

--- 172.18.150.54 ping statistics ---
3 packets transmitted, 3 received, 0% packet loss, time 2034 ms
rtt min/avg/max = 0/16/33 ms

->
-> █
```


4.7 The RTU's MAC Address

4.7.1 Finding RTU's MAC Address Using Console

Enter the command shown below to retrieve the MAC address of the Ethernet circuits on the CPU card.

Figure 4-4 Finding the CPU Card's MAC Address Using Console

```

COM1 - PuTTY
->
->
->
->
->
-> cmd
[vxWorks]# ifconfig -a
lo0    Link type:Local loopback  Queue:none
       inet 127.0.0.1  mask 255.255.255.255
       UP RUNNING LOOPBACK MULTICAST
       MTU:1500  metric:1  VR:0  ifindex:1
       RX packets:14 mcast:0 errors:0 dropped:4
       TX packets:14 mcast:0 errors:0
       collisions:0 unsupported proto:0
       RX bytes:616  TX bytes:616

fei0    Link type:Ethernet  HWaddr 00:04:bf:92:28:e9  Queue:none
       capabilities: TXCSUM VLAN_MTU VLAN_TXHWTAG VLAN_RXHWTAG
       inet 172.18.150.51  mask 255.255.248.0  broadcast 172.18.151.255
       UP RUNNING SIMPLEX BROADCAST MULTICAST
       MTU:1500  metric:1  VR:0  ifindex:2
       RX packets:11578 mcast:5054 errors:0 dropped:202
       TX packets:6 mcast:0 errors:0
       collisions:0 unsupported proto:0
       RX bytes:1165k  TX bytes:438

ppp0    Link type:Point to point  Queue:none
       inet 0.0.0.0  mask 255.255.255.255  peer 0.0.0.0
       RUNNING POINTOPOINT MULTICAST
       MTU:1500  metric:2  VR:0  ifindex:3
       RX packets:0 mcast:0 errors:0 dropped:0
       TX packets:21 mcast:0 errors:0
       collisions:0 unsupported proto:0
       RX bytes:0  TX bytes:393

fei1    Link type:Ethernet  HWaddr 00:04:bf:92:28:ea  Queue:none
       capabilities: TXCSUM VLAN_MTU VLAN_TXHWTAG VLAN_RXHWTAG
       inet 172.18.150.151  mask 255.255.0.0  broadcast 172.18.255.255
       UP SIMPLEX BROADCAST MULTICAST
       MTU:1500  metric:1  VR:0  ifindex:4
       RX packets:0 mcast:0 errors:0 dropped:0
       TX packets:0 mcast:0 errors:0
       collisions:0 unsupported proto:0
       RX bytes:0  TX bytes:0


[vxWorks]#
  
```

Note: Secondary Ethernet (fei1) is displayed only if the device has been configured via the GUI / Application firmware.


4.7.2 Finding RTU's MAC Address Remotely

If the console cannot be used remotely, you can find the MAC address through a Windows command line using the ARP command as follows if your PC is directly connected to the RTU. Otherwise, you will have to connect to the device serving as the gateway to the network for the RTU and use the ARP command appropriate for the device.

Go to Start and Run.



Click OK for cmd.



When you type arp alone, the Command window returns the definition of the command and all its modifiers.

Figure 4-5 The ARP Command

```

C:\WINDOWS\system32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\tubgr>arp

Displays and modifies the IP-to-Physical address translation tables used by
address resolution protocol (ARP).

ARP -s inet_addr eth_addr [if_addr]
ARP -d inet_addr [if_addr]
ARP -a [inet_addr] [-N if_addr]

-a          Displays current ARP entries by interrogating the current
             protocol data. If inet_addr is specified, the IP and Physical
             addresses for only the specified computer are displayed. If
             more than one network interface uses ARP, entries for each ARP
             table are displayed.
-g          Same as -a.
inet_addr   Specifies an internet address.
-N if_addr  Displays the ARP entries for the network interface specified
             by if_addr.
-d          Deletes the host specified by inet_addr. inet_addr may be
             wildcarded with * to delete all hosts.
-s          Adds the host and associates the Internet address inet_addr
             with the Physical address eth_addr. The Physical address is
             given as 6 hexadecimal bytes separated by hyphens. The entry
             is permanent.
eth_addr    Specifies a physical address.
if_addr     If present, this specifies the Internet address of the
             interface whose address translation table should be modified.
             If not present, the first applicable interface will be used.


Example:
> arp -s 157.55.85.212 00-aa-00-62-c6-09 .... Adds a static entry.
> arp -a                                     .... Displays the arp table.

C:\Documents and Settings\tubgr>_

```

To find the Primary Port MAC address (Ethernet Port 0), Ping the IP address of the Primary Port in the RTU to establish a network connection. Then enter "ARP -a" as shown. The Physical Address displayed is the MAC Address.

Figure 4-6 Finding the CPU Card's MAC Address Remotely



```
C:\WINDOWS\system32\cmd.exe

C:\Documents and Settings\tubgr>ping 172.18.150.171

Pinging 172.18.150.171 with 32 bytes of data:

Reply from 172.18.150.171: bytes=32 time<1ms TTL=64
Reply from 172.18.150.171: bytes=32 time=20ms TTL=64
Reply from 172.18.150.171: bytes=32 time<1ms TTL=64
Reply from 172.18.150.171: bytes=32 time<1ms TTL=64

Ping statistics for 172.18.150.171:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 20ms, Average = 5ms

C:\Documents and Settings\tubgr>arp -a

Interface: 172.18.145.62 --- 0x3
    Internet Address      Physical Address         Type
    172.18.144.16         00-14-22-78-40-6d       dynamic
    172.18.144.17         00-1e-4f-1b-a6-1f       dynamic
    172.18.150.171        00-04-bf-92-30-16       dynamic
    172.18.151.254        00-1f-c9-f5-d4-08       dynamic

C:\Documents and Settings\tubgr>_
```

The screenshot shows a Windows command prompt window titled "C:\WINDOWS\system32\cmd.exe". The user is logged in as "tubgr". The first command executed is "ping 172.18.150.171", which successfully pings the target IP address with four replies. The second command is "arp -a", which displays the ARP table. The table lists four entries for the interface 172.18.145.62. A white arrow points to the entry for IP address 172.18.150.171, which has a physical address of 00-04-bf-92-30-16.

Note: To find the MAC address of the Secondary Port (Ethernet Port 1), set the computer's IP address in the same group as the RTU so that the Ping command and the ARP command will see the Secondary Port of the RTU. Then repeat the Ping and ARP commands above using the IP Address of the Secondary Port.

4.8 SBO Troubleshooting

Beginning with C3413-500-001C6 and newer firmware, the following function is available through the console to help trouble shoot the SBO bus. This function is valid only for the C3400 (SAGE 2300/SAGE 2400) and C3800 (SAGE 3030/SAGE 3030M) baseboards.

To use this function, connect your PC to the console port on the RTU and start the terminal emulation program. Type the <Enter> key and make sure that you get the "->" prompt.

Start the GUI and log on. Make sure to disconnect the field wiring from the point you are going to operate and perform the Trip or Close that does not work.

Type "c34_print_sbo_table" on the console (don't type the double quotes). After you have typed this in one time, you can type an "<ESC>k" to recall the history and type a "<Enter>" to execute the function again.

The following display is a successful trip of point 4 on the baseboard. If you have multiple executes (execute read - more than one bit set) or multiple selects (select read - more than one bit clear), the SBO control will fail. All of the IOPLD values will be 00 on a successful operation. The rt section of the display is valid only when the RTU detects a control error in real time. In this case, the RTU has started to perform the control but detects an error while the control is active. The selects expected and read, executes expected and read, and the time the relay was expected to close and time left to close to completion is displayed.

```
-> c34_print_sbo_table
progress counter      60
select expected      bfff
select read          bfff
execute expected      0001
execute read          0001
sel shift loops       0
driver chk loops      0
IOPLD_EXECUTE         00
IOPLD_DID              00
IOPLD_SBO_CSEL_HI     00
IOPLD_SBO_CSEL_LO     00
IOPLD_SBO_CEXEC_READ_LO 00
IOPLD_SBO_CEXEC_READ_HI 00
rt select expected     0000
rt select read         0000
rt execute expected    0000
rt execute read        0000
rt time expected       0
rt time left err       0
value = 25 = 0x19
```

->

The following display is a execute fail trip of point 4 on the baseboard. Note that execute 0 and execute 7 (CEXEC0 and CEXEC7 on the schematics) are both 1. Execute 0 is used for the baseboard relays or the last XT position on the SBO bus if the baseboard points are disabled.

```
-> c34_print_sbo_table
progress counter    50
select expected    bfff
select read        bfff
execute expected    0001
execute read        0081
sel shift loops     0
driver chk loops    0
IOPLD_EXECUTE       00
IOPLD_DID            00
IOPLD_SBO_CSEL_HI    00
IOPLD_SBO_CSEL_LO    00
IOPLD_SBO_CEXEC_READ_LO 00
IOPLD_SBO_CEXEC_READ_HI 00
rt select expected   0000
rt select read       0000
rt execute expected  0000
rt execute read      0000
rt time expected     0
rt time left err     0
value = 25 = 0x19
->
```

The following display is of a select fail, trip of point 4 on the baseboard. Note that select 14 and select 15 (CSEL14 and CSEL15 on the schematics) are both 0. The high byte of the selects is used for the baseboard relays.

```
-> c34_print_sbo_table
progress counter    30
select expected    bfff
select read        3fff
execute expected    0000
execute read        0000
sel shift loops     0
driver chk loops    0
IOPLD_EXECUTE      00
IOPLD_DID           00
IOPLD_SBO_CSEL_HI   00
IOPLD_SBO_CSEL_LO   00
IOPLD_SBO_CEXEC_READ_LO 00
IOPLD_SBO_CEXEC_READ_HI 00
rt select expected  0000
rt select read      0000
rt execute expected 0000
rt execute read     0000
rt time expected    0
rt time left err    0
value = 25 = 0x19
->
```

The progress counter code indicates the error/success code.

At reset or if there was an error detected on a previous SBO operation, a reset function is called to determine if the problem has cleared. These are the codes that this function produces.

- 100 initial check of registers on the baseboard failed, should have nonzero values in the IOPLD values
- 110 shifting of the select bits failed (shift in progress bit not set)
- 115 shifting of the select bits failed (shift in progress bit not clear)
- 120 execute bit stuck on
- 130 select bit stuck on
- 140 completion check of registers on the baseboard failed, should have nonzero values in the IOPLD values

These are the codes produced by the normal operation of the SBO control system.

- 10 check of registers on the baseboard failed, should have nonzero values in the IOPLD values
- 20 relay number out of range
- 30 select fail
- 40 check of registers on the baseboard failed, should have nonzero values in the IOPLD values
- 50 execute fail
- 60 successful operation

The following tables show the relationship between the control lines and the relays being controlled.

The Execute/Select column is based on the schematic. The digit before the “/” is the Execute number. The digit after the “/” is the Select number. For example, 0/8 CEXEC0/CSEL8. This combination is point 1 Trip.

Table 4-1 C3400 SBO Relay Assignments with Baseboard Enabled

Location	SBO Database Relay #	Sequential Relay #	Execute/Select	Comments
			0/0 to 0/7	do not exist
	1 trip to 4 close	1 to 8	0/8 to 0/15	baseboard relays
Bank 1 J7	5 trip to 12 close	9 to 24	1/0 to 1/15	1st 16-relay SBO XT
	13 trip to 20 close	25 to 40	2/0 to 2/15	2nd 16-relay SBO XT
	21 trip to 28 close	41 to 56	3/0 to 3/15	3rd 16-relay SBO XT
	29 trip to 36 close	57 to 72	4/0 to 4/15	4th 16-relay SBO XT
	37 trip to 44 close	73 to 88	5/0 to 5/15	5th 16-relay SBO XT
	45 trip to 52 close	89 to 104	6/0 to 6/15	6th 16-relay SBO XT
	53 trip to 60 close	105 to 120	7/0 to 7/15	7th 16-relay SBO XT
Bank 2 J8	61 trip to 68 close	121 to 136	8/0 to 0/15	8th 16-relay SBO XT
	69 trip to 76 close	137 to 152	9/0 to 1/15	9th 16-relay SBO XT
	77 trip to 84 close	153 to 168	10/0 to 2/15	10th 16-relay SBO XT
	85 trip to 92 close	169 to 184	11/0 to 3/15	11th 16-relay SBO XT
	93 trip to 100 close	185 to 200	12/0 to 4/15	12th 16-relay SBO XT
	101 trip to 108 close	201 to 216	13/0 to 5/15	13th 16-relay SBO XT
	109 trip to 116 close	217 to 232	14/0 to 6/15	14th 16-relay SBO XT
	117 trip to 124 close	233 to 248	15/0 to 7/15	15th 16-relay SBO XT

The Execute/Select column is based on the schematic. The digit before the “/” is the Execute number. The digit after the “/” is the Select number. For example, 0/8 CEEXEC0/CSEL8. This combination is point 61 Trip.

Table 4-2 C3400 SBO Relay Assignments with Baseboard Disabled

Location	SBO Database Relay #	Sequential Relay #	Execute/Select	Comments
Bank 1 J4	1 trip to 8 close	1 to 16	1/0 to 1/15	1st 16-relay SBO XT
	9 trip to 16 close	17 to 32	2/0 to 2/15	2nd 16-relay SBO XT
	17 trip to 24 close	33 to 48	3/0 to 3/15	3rd 16-relay SBO XT
	25 trip to 32 close	49 to 64	4/0 to 4/15	4th 16-relay SBO XT
	33 trip to 40 close	65 to 80	5/0 to 5/15	5th 16-relay SBO XT
	41 trip to 48 close	81 to 96	6/0 to 6/15	6th 16-relay SBO XT
	49 trip to 56 close	97 to 112	7/0 to 7/15	7th 16-relay SBO XT
	57 trip to 64 close	113 to 128	0/0 to 0/15	8th 16-relay SBO XT
Bank 2 J3	65 trip to 72 close	129 to 144	8/0 to 8/15	9th 16-relay SBO XT
	73 trip to 80 close	145 to 160	9/0 to 9/15	10th 16-relay SBO XT
	81 trip to 88 close	161 to 176	10/0 to 10/15	11th 16-relay SBO XT
	89 trip to 96 close	177 to 192	11/0 to 11/15	12th 16-relay SBO XT
	97 trip to 104 close	193 to 208	12/0 to 12/15	13th 16-relay SBO XT
	105 trip to 112 close	209 to 224	13/0 to 13/15	14th 16-relay SBO XT
	113 trip to 120 close	225 to 240	14/0 to 14/15	15th 16-relay SBO XT
	121 trip to 128 close	241 to 256	15/0 to 15/15	16th 16-relay SBO XT

Table 4-3 C3800 SBO Relay Assignments

Location	SBO Database Relay #	Sequential Relay #	Execute/Select	Comments
			0/0 to 0/15	do not exist
Bank 1 J3	1 trip to 8 close	1 to 16	1/0 to 1/15	1st 16-relay SBO XT
	9 trip to 16 close	17 to 32	2/0 to 2/15	2nd 16-relay SBO XT
	17 trip to 24 close	33 to 48	3/0 to 3/15	3rd 16-relay SBO XT
	25 trip to 32 close	49 to 64	4/0 to 4/15	4th 16-relay SBO XT
	33 trip to 40 close	65 to 80	5/0 to 5/15	5th 16-relay SBO XT
	41 trip to 48 close	81 to 96	6/0 to 6/15	6th 16-relay SBO XT
	49 trip to 56 close	97 to 112	7/0 to 7/15	7th 16-relay SBO XT

Table 4-4 C3800 / C3810 LANDAC II SBO Relay Assignments

Location	SBO Database Relay #	Sequential Relay #	Execute/Select	Comments
Bank 1 J7 (C3810)	1 trip to 8 close	1 to 16	1/0 to 1/15	1st 16-relay SBO XT
	9 trip to 16 close	17 to 32	2/0 to 2/15	2nd 16-relay SBO XT
	17 trip to 24 close	33 to 48	3/0 to 3/15	3rd 16-relay SBO XT
	25 trip to 32 close	49 to 64	4/0 to 4/15	4th 16-relay SBO XT
	33 trip to 40 close	65 to 80	5/0 to 5/15	5th 16-relay SBO XT
	41 trip to 48 close	81 to 96	6/0 to 6/15	6th 16-relay SBO XT
	49 trip to 56 close	97 to 112	7/0 to 7/15	7th 16-relay SBO XT
	57 trip to 64 close	113 to 128	0/0 to 0/15	8th 16-relay SBO XT
Bank 2 J8 (C3810)	65 trip to 72 close	129 to 144	8/0 to 8/15	9th 16-relay SBO XT
	73 trip to 80 close	145 to 160	9/0 to 9/15	10th 16-relay SBO XT
	81 trip to 88 close	161 to 176	10/0 to 10/15	11th 16-relay SBO XT
	89 trip to 96 close	177 to 192	11/0 to 11/15	12th 16-relay SBO XT
	97 trip to 104 close	193 to 208	12/0 to 12/15	13th 16-relay SBO XT
	105 trip to 112 close	209 to 224	13/0 to 13/15	14th 16-relay SBO XT
	113 trip to 120 close	225 to 240	14/0 to 14/15	15th 16-relay SBO XT
	121 trip to 128 close	241 to 256	15/0 to 15/15	16th 16-relay SBO XT
Bank 3 J9 (C3800)	129 trip to 136 close	257 to 272	1/0 to 1/15	17th 16-relay SBO XT
	137 trip to 144 close	273 to 288	2/0 to 2/15	18th 16-relay SBO XT
	145 trip to 152 close	289 to 304	3/0 to 3/15	19th 16-relay SBO XT
	153 trip to 160 close	305 to 320	4/0 to 4/15	20th 16-relay SBO XT
	161 trip to 168 close	321 to 336	5/0 to 5/15	21th 16-relay SBO XT
	169 trip to 176 close	337 to 352	6/0 to 6/15	22th 16-relay SBO XT
	177 trip to 184 close	353 to 368	7/0 to 7/15	23th 16-relay SBO XT
	185 trip to 192 close	369 to 384	0/0 to 0/15	24th 16-relay SBO XT

The tables above have a Execute/Select column. The format of the information displayed is Execute/Select order (execute is before the slash, the select follows the slash). The following tables convert the Execute and Select to the bit patterns displayed in c34_print_sbo_table.

The Select will be displayed in the c34_print_sbo_table as the following bit patterns:

Table 4-5 Select Bit Patterns

Select	Bit Pattern
0	FFFE
1	FFFD
2	FFFB
3	FFF7
4	FFEF
5	FFDF
6	FFBF
7	FF7F
8	FEFF
9	FDFE
10	FBFF
11	F7FF
12	FFFF
13	DFFF
14	BFFF
15	7FFF

The Execute will be displayed in the c34_print_sbo_table as the following bit patterns:

Table 4-6 Execute Bit Patterns

Execute	Bit Pattern
0	0001
1	0002
2	0004
3	0008
4	0010
5	0020
6	0040
7	0080
8	0100
9	0200
10	0400
11	0800
12	1000
13	2000
14	4000
15	8000

4.9 Restoring the RTU to a Known State

If the firmware in the compact flash is in an unstable state but still bootable, you may be able to restore it to a known configuration. Once it has been restored to this known configuration, a stable system will be in place so that you can use SFTP to restore the compact flash.

The UIF cable must be connected to your PC with a terminal emulator program running to determine if this is possible, and if so, perform the steps to install the system. The UIF serial configuration is 1 start, 8 data, no parity, and 1 stop bit @ 9600 baud, no flow control.

This capability exists on VxWorks versions greater than the 6.7 version. At bootup, the following (or similar) information is displayed as part of the startup sequence.

```
CPU: PC PENTIUM2
Version: VxWorks 6.7
BSP version: 2.0/10
Creation date: Aug 27 2009, 09:46:21
```

If the string “Version: VxWorks 6.7” is displayed, this capability is not available and it will be difficult to restore a system.

If the string “Version: VxWorks 6.8” or higher is displayed, this function is available. Older versions do not have the features in the boot ROM code required to restore to a known configuration.

To restore to the known configuration:

- 1) Reboot the RTU
- 2) Enter any key to stop the boot up process when you see the following prompt:

Press any key to stop auto-boot...

Type the following at the *[VxWorks Boot]:* prompt:

```
[VxWorks Boot]: cd /ata0a/recovery
[VxWorks Boot]: cp VxWorks /ata0a
[VxWorks Boot]: cp recovery.scp /ata0a/scripts/vxworks_start.scp
[VxWorks Boot]: @
```

The RTU should automatically restore itself to the initial state.

The IP address of the recovered RTU will be 192.168.1.1:255.255.0.0

The Username is Admin. The password is Telvent1!

You can now login to the RTU using a SFTP client after you make the private key file “Admin.ppk” distributed with the S02 Update File known to the client.

After you login to the RTU, you may transfer a new Firmware, Configuration, and User Access packages to the /ata0a/install directory.